

Syvecs PNP Auxiliary Connector Pinouts

As those who have installed their own S6PnP units will have noticed, there are 5 additional connectors on the rear edge of the board. Below are the pinouts for these connectors looking from the back of the mating connectors:

(PLEASE NOTE, EVO PNP BOARD HAS COMMS PINOUT BACKWARD)



Comms:

Pin 1 - RS232 RX

Pin 2 - RS232 TX

Pin 3 - Comms GND

Pin 4 - CAN HI

Pin 5 - CAN LO

Pin 6 - Power GND

Ethernet:

Pin 1 - LAN TX+

Pin 2 - LAN TX-

Pin 3 - LAN RX+

Pin 4 - Not Connected

Pin 5 - Not Connected

Pin 6 - LAN RX-

Pin 7 - Not Connected

Pin 8 - Not Connected

UEGO LAMBDA:

Pin 1 - LAM V (Nernst Cell Voltage) (Red or Grey)

Pin 2 - LAM I (Ion Pump Current) (White)

Pin 3 - LAM GND (Cell Ground) (Black)

Pin 4 - VBAT (Heater +) (Orange or Blue)

Pin 5 - INJ* (Heater -) (Yellow)

Pin 6 - PWRGND

NB: Pin 5 is version specific, check the actual pinout using Calibration -> Comments. Subaru MY99/00 has INJ8, for example.

Auxiliary:

Pin 1 - IGN1 / PWRGND

Pin 2 - IGN2 / PWRGND

Pin 3 - IGN3 / PWRGND

Pin 4 - IGN4 / PWRGND

Pin 5 - IGN5 / PWRGND

Pin 6 - IGN6 / PWRGND

Pin 7 - VBAT

Pin 8 - 12VOUT

Pin 9 - 5VOUT#2

Pin 10 - ANGDN#2 (Sensor Ground)

Pin 11 - Not Connected (Reserved)

Pin 12 - Not Connected (Reserved)

NB: Pins 1-6 only connected to free outputs, so Subaru MY99/00 has pins 1&2 to PWRGND, IGN3-6 are available though. MY92-96 on the other hand has pins 1 to 4 to PWRGND, only IGN5&6 are available. 12VOUT is low current, use only for sensors.

Thermocouple

This connector is a standard miniture K-Type, if a sensor is wired correctly and plugged in it will work. NB: The linearisation for any sensor configured to use this input should be flatline 0 this will cause the built in curve to be used. It is possible to specify custom curves but this is only appropriate to the most advanced engine developers.

General Notes

These connectors have a standard pinout. Any future products will feature the same pinout, so a lead made for an NTK sensor for a Subaru MY92-96 will work fine on an Evo VIII carrier board. Any external interfaces created to these pinouts should be inherently safe if moved from one model to another; moving an external device which used IGN3 on an MY99 board to an MY92 board will cause that function to simply turn off, rather than be in an uncertain state.