

# SYVECS LTD

V1.1



## Audi RS3 8Y2 Plug in kit- S7D

This document is intended for use by a technical audience and describes a number of procedures that are potentially hazardous. Installations should be carried out by competent persons only.

Syvecs and the author accept no liability for any damage caused by the incorrect installation or configuration of the equipment.

Please Note that due to frequent firmware changes certain windows might not be the same as the manual illustrates. If so please contact the Syvecs Tech Team for Assistance.

[Support@Syvecs.com](mailto:Support@Syvecs.com)

## Parts Supplied:

- Syvecs S7D
- ECU Acc Connector

## Installation

1 Remove the Negative Terminal from the battery on the Vehicle to be extra safe with electrical components. This is found in the rear boot under the carpet.



2 Unplug the Current Sense connector on the battery and leave this disconnected. (Allows Maximum Charging)



### 3 Unplug and Remove the Factory ECU




### 4 Remove the front and rear ECU bracket nut



### 5 Remove the original ECU Bracket.



**6** Replace the Original ECU bracket with VAG Part 5Q0906507F



**7** Mount the S7D into the new bracket and plug in the provided 26 way acc connector and run the ethernet cable into the Cabin



**8** Reconnect the battery Negative Terminal and proceed to loading a base calibration to the Ecu.

- <https://www.youtube.com/watch?v=jqDPKCQYzo0&t=195s>

# Calibration Switching

The Cruise lever on the RS3 8Y is used to do calibration switching on the Syvecs Ecu.

Cruise Down = Cal Down

Cruise Up = Cal Up

Cruise On - Cruise Switch

Cruise Back - Cal Override (Rolling Antilag)



The Rpm Gauge will show the active CalSelect selection when changing is performed via cruise levers. The HP Gauge will also show Ethanol Content



# Custom Features

**FlexFuel Content** - The original dash displays the Ethanol content (FuelComp) in the Power Gauge on the dash when changing calibration switch position. It is displayed for 1 Second.



**Map Sensor Selection** - The OEM Map sensor is SENT Protocol on the RS3 and its limited with its range. Some owners decide they wish to fit increased pressure which are 0-5v output instead of SENT.



SENT MAP Sensor



0-5V ADC MAP Sensor

This is possible by changing the Input Configuration of the Map Sensor under sensors.

5V Bipolar = SENT Protocol

5v = 0-5v ADC




## Support / Training

Dealer Support can be obtained from [Support@Syvecs.com](mailto:Support@Syvecs.com)  
End Users Support from Syvecs Forum

A getting started help video is found here for plug in kits  
<https://www.youtube.com/watch?v=jqDPKCQYzo0&t=1498s>



More Syvecs Help videos can be found on our YouTube Page  
[www.youtube.com/SyvecsHelp](http://www.youtube.com/SyvecsHelp)



# Pinouts

| <i>Syvecs Description</i>        | <i>Syvecs S7D Pinout</i> | <i>Function</i>                    | <i>OEM Function</i>         |
|----------------------------------|--------------------------|------------------------------------|-----------------------------|
| <b>A</b>                         | DESCRIPTION              | CONNECTOR A                        |                             |
|                                  | PART NUMBER              | 4-1437290-0                        |                             |
|                                  | NOTES:                   | 34 Way - Key1                      |                             |
| PWR CTR OUT                      | A1                       | MAIN RELAY OUTPUT                  |                             |
| H-Bridge1                        | A2                       | H-Bridge1                          | DBW +                       |
| H-Bridge2                        | A3                       | H-Bridge2                          | DBW -                       |
| H-Bridge3                        | A4                       | H-Bridge3                          | WG Solenoid                 |
| H-Bridge4                        | A5                       | H-Bridge4                          | Evap                        |
| H-Bridge5                        | A6                       | H-Bridge5                          | Spare Output                |
| H-Bridge6                        | A7                       | H-Bridge6                          | Starter Relay               |
| H-Bridge7                        | A8                       | H-Bridge7                          | Intake Manifold Flap (N316) |
| H-Bridge8                        | A9                       | H-Bridge8                          | Coolant Switch Pump         |
| GDI LS1                          | A10                      | Fuel 1 / Low Side GDI 1            | Spare Output                |
| GDI LS2                          | A11                      | Low Side GDI 2                     | Injector 4 -                |
| GDI LS3                          | A12                      | Fuel 3 / Low Side GDI 3            | Port Injector 1 (N532)      |
| GDI LS4                          | A13                      | Low Side GDI 4                     | Injector 2 -                |
| GDI LS5                          | A14                      | Fuel 5 / Low Side GDI 5            | Port Injector 2 (N533)      |
| GDI LS6                          | A15                      | Low Side GDI 6                     | Injector 5 -                |
| GDI LS7                          | A16                      | Fuel 7 / Low Side GDI 7            | Port Injector 3 (N534)      |
| GDI LS8                          | A17                      | Low Side GDI 8                     | Injector 3 -                |
| GDI HS1/2                        | A18                      | GDI HI Side 1-2                    | Injector 4 +                |
| GDI HS3/4                        | A19                      | GDI HI Side 3-4                    | Injector 2 +                |
| GDI Pump 1 HS                    | A20                      | GDI Pump 1 Hi Side                 | GDI Pump HS                 |
| GDI HS5/6                        | A21                      | GDI HI Side 5-6                    | Injector 5 +                |
| GDI HS7/8                        | A22                      | GDI HI Side 7-8                    | Injector 3+                 |
| GDI Pump 2 HS                    | A23                      | GDI Pump 2 Hi Side                 | Injector 1+                 |
| GDI Pump 1 LowSide               | A24                      | GDI Pump 1 Lo Side / Fuel15 Output | GDI Pump LS                 |
| GDI Pump 2 LowSide / Injector LS | A25                      | GDI Pump 2 Lo Side / Fuel16 Output | Injector 1 -                |
| IGN1                             | A26                      | CYL 1 IGNITION OUTPUT              | IGN1 (N70)                  |
| IGN2                             | A27                      | CYL 2 IGNITION OUTPUT              | IGN2 (N127)                 |
| IGN3                             | A28                      | CYL 3 IGNITION OUTPUT              | IGN3 (N291)                 |
| IGN4                             | A29                      | CYL 4 IGNITION OUTPUT              | IGN4 (N292)                 |
| IGN5                             | A30                      | CYL 5 IGNITION OUTPUT              | IGN5 (N292)                 |
| IGN6                             | A31                      | CYL 6 IGNITION OUTPUT              | Tacho Sync                  |
| PWRGND                           | A32                      | POWER GROUND                       | PwrGnd                      |
| PWRGND                           | A33                      | POWER GROUND                       | PwrGnd                      |
| PWRGND                           | A34                      | POWER GROUND                       | PwrGnd                      |

| <i>Syvecs Description</i> | <i>Syvecs S7D Pinout</i> | <i>Function</i>         | <i>OEM Function</i> |
|---------------------------|--------------------------|-------------------------|---------------------|
| <b>B</b>                  | DESCRIPTION              | CONNECTOR B             |                     |
|                           | PART NUMBER              | 3-1437290-7             |                     |
|                           | NOTES:                   | 26 Way - Key1           |                     |
| PWRGND                    | B1                       | POWER GROUND            | PwrGnd              |
| CAN2 L                    | B2                       | Can 2                   |                     |
| CAN2 H                    | B3                       | Can 2                   |                     |
| KNOCK 1                   | B4                       | KNOCK 1                 |                     |
| KNOCK 2                   | B5                       | KNOCK 2                 |                     |
| PVBAT                     | B6                       | CONSTANT 12V            |                     |
| IVBAT                     | B7                       | 12v                     |                     |
| LAM1A                     | B8                       | Lamv / LamD1+ / LamLun1 |                     |
| LAM1B                     | B9                       | Lami / LamD1- / LamIP1  |                     |
| LAM1C                     | B10                      | LamLIA1                 |                     |
| LAM1D                     | B11                      | LamGND / LamLVM1        |                     |
| LAM1HEATER                | B12                      | LAMBDA HEATER           |                     |
| IVBAT                     | B13                      | 12V                     |                     |
| LAM2A                     | B14                      | Lamv / LamD1+ / LamLun1 |                     |
| LAM2B                     | B15                      | Lami / LamD1- / LamIP1  |                     |
| LAM2C                     | B16                      | LamLIA1                 |                     |
| LAM2D                     | B17                      | LamGND / LamLVM1        |                     |
| LAM2HEATER                | B18                      | LAMBDA HEATER           |                     |
| IVBAT                     | B19                      | 12V                     |                     |
| KLINE                     | B20                      | KLINE                   |                     |
| RS232RX                   | B21                      | RS232RX                 |                     |
| RS232TX                   | B22                      | RS232TX                 |                     |
| LANRX-                    | B23                      | Cat5 Pin2               |                     |
| LANRX+                    | B24                      | Cat5 Pin1               |                     |
| LANTX-                    | B25                      | Cat5 Pin6               |                     |
| LANTX+                    | B26                      | Cat5 Pin3               |                     |

# Pinouts

| <b>C</b>   |     | DESCRIPTION         | CONNECTOR C   |                          |
|------------|-----|---------------------|---------------|--------------------------|
|            |     | PART NUMBER         | 4-1437290-1   |                          |
|            |     | NOTES:              | 34 Way - Key2 |                          |
|            |     |                     |               |                          |
| KNOCKGND   | C1  | KNOCKGND            |               | Knock -                  |
| ANGND      | C2  | SENSOR GND          |               |                          |
| ANGND      | C3  | SENSOR GND          |               |                          |
| ANGND      | C4  | SENSOR GND          |               |                          |
| 5V OUT     | C5  | 5V OUT              |               |                          |
| 5V OUT     | C6  | 5V OUT              |               |                          |
| 5V OUT     | C7  | 5V OUT              |               |                          |
| CAN1 L     | C8  | Can 1 Low           |               | Powertrain Can           |
| CAN1 H     | C9  | Can 1 High          |               | Powertrain Can           |
| AN01       | C10 | BI-POLAR INPUTS     |               | Start Request            |
| AN02       | C11 | BI-POLAR INPUTS     |               | Di Pressure              |
| AN03       | C12 | BI-POLAR INPUTS     |               | Spare Input              |
| AN04       | C13 | BI-POLAR INPUTS     |               | Spare Input              |
| AN05       | C14 | UNI-POLAR INPUTS    |               | VVT1In Pos               |
| AN06       | C15 | UNI-POLAR INPUTS    |               | VVT1Ex Pos               |
| AN07       | C16 | UNI-POLAR INPUTS    |               | Crank Sensor             |
| AN08       | C17 | UNI-POLAR INPUTS    |               | Brake Lt Sw              |
| AN09       | C18 | VOLT-INPUTS         |               | TPS1A                    |
| AN10       | C19 | VOLT-INPUTS         |               | TPS1B                    |
| AN11       | C20 | VOLT-INPUTS         |               | Map                      |
| AN12       | C21 | VOLT-INPUTS         |               | Spare Input              |
| AN13       | C22 | RESISTIVE INPUTS    |               | Coolant Temp (G62)       |
| AN14       | C23 | RESISTIVE INPUTS    |               | Intake Air Temp          |
| AN15       | C24 | RESISTIVE INPUTS    |               | EGT1                     |
| AN16       | C25 | RESISTIVE INPUTS    |               | EGT2                     |
| EGT1-      | C26 | EGT1 -              |               |                          |
| EGT1+      | C27 | EGT1 +              |               |                          |
| PWR CTR IN | C28 | MAIN RELAY INPUT SW |               | Key On sig (15)          |
| AN S1      | C29 | UNI-POLAR INPUTS    |               | Intake Pos Flap          |
| AN S2      | C30 | UNI-POLAR INPUTS    |               | Fuel Pressure Low Side   |
| AN S3      | C31 | UNI-POLAR INPUTS    |               | PPSA                     |
| AN S4      | C32 | UNI-POLAR INPUTS    |               | PPSB                     |
| AN S5      | C33 | UNI-POLAR INPUTS    |               | Pre Throttle Map         |
| AN S6      | C34 | UNI-POLAR INPUTS    |               | InterMediate Shaft Speed |

| <i>Syvecs Description</i> | <i>Syvecs S7D Pinout</i> | <i>Function</i>   | <i>OEM Function</i>     |
|---------------------------|--------------------------|-------------------|-------------------------|
| <b>D</b>                  | DESCRIPTION              | CONNECTOR D       |                         |
|                           | PART NUMBER              | 3-1437290-8       |                         |
|                           | NOTES:                   | 26 Way - Key2     |                         |
|                           |                          |                   |                         |
| DVBAT1                    | D1                       | GDI Power Supply  |                         |
| DVBAT2                    | D2                       | GDI Power Supply  |                         |
| DVBAT3                    | D3                       | GDI Power Supply  |                         |
| DVBAT4                    | D4                       | GDI Power Supply  |                         |
| FUEL9                     | D5                       | PWM / FUEL OUTPUT | Port Injector 4 (N535)  |
| FUEL10                    | D6                       | PWM / FUEL OUTPUT | Port Injector 5 (N536)  |
| FUEL11                    | D7                       | PWM / FUEL OUTPUT | Fuel Pump PWM           |
| FUEL12                    | D8                       | PWM / FUEL OUTPUT | Cooling Fan PWM         |
| FUEL13                    | D9                       | PWM / FUEL OUTPUT | Turbo Recirc (N249)     |
| FUEL14                    | D10                      | PWM / FUEL OUTPUT | Exhaust Cam Solenoids A |
| LSO1                      | D11                      | PWM OUTPUT        | VVT1 Int (N205)         |
| LSO2                      | D12                      | PWM OUTPUT        | VVT1 Ex (N316)          |
| LSO3                      | D13                      | PWM OUTPUT        | Oil Pressure Valve      |
| LSO4                      | D14                      | PWM OUTPUT        | Crank Case Breather     |
| LSO5                      | D15                      | PWM OUTPUT        | Coolant Shut Off Valve  |
| LSO6                      | D16                      | PWM OUTPUT        | Coolant Pump PWM        |
| EGT2-                     | D17                      | EGT2 -            |                         |
| EGT2+                     | D18                      | EGT2 +            |                         |
| NC                        | D19                      | NC                |                         |
| NC                        | D20                      | NC                |                         |
| NC                        | D21                      | NC                |                         |
| NC                        | D22                      | NC                |                         |
| CAN3L                     | D23                      | CAN3L             | CAN3L                   |
| CAN3H                     | D24                      | CAN3H             | CAN3H                   |
| PWRGND                    | D25                      | POWER GROUND      |                         |
| PWRGND                    | D26                      | POWER GROUND      |                         |

# Acc Connector Pinouts



| ACC | DESCRIPTION |                                     |
|-----|-------------|-------------------------------------|
|     | PART NUMBER | 3-1437290-7                         |
|     | NOTES:      | 26 Way - Key1                       |
|     |             |                                     |
| B1  | GND         | Ground                              |
| B2  | Fuel 1      | Spare Output                        |
| B3  | LSO3        | Spare Output - Slave1 Out13         |
| B4  | LSO4        | Spare Output - Slave1 Out14         |
| B5  | LSO5        | Spare Output - Slave1 Out15         |
| B6  | LSO6        | Spare Output - Slave1 Out16         |
| B7  | 12v         |                                     |
| B8  | H-Bridge 5  | Spare Output - Slave1 Out5          |
| B9  | CAN2L       | Spare CAN                           |
| B10 | CAN2H       | Spare CAN                           |
| B11 | RS232RX     |                                     |
| B12 | RS232TX     |                                     |
| B13 | LAM2A       | Spare Input - S1AN08                |
| B14 | EGT1-       | K-Type EGT                          |
| B15 | EGT1+       | K-Type EGT                          |
| B16 | AN03        | Spare Input - BiPolar               |
| B17 | AN04        | Spare Input - BiPolar               |
| B18 | AN15        | Spare Input                         |
| B19 | AN16        | Spare Input                         |
| B20 | S1AN4       | Spare Input if NON SENT Map is used |
| B21 | ANGround    | Sensor Ground                       |
| B22 | 5V Out      | 5v Output for Sensors               |
| B23 | Cat5 Pin2   | Ethernet                            |
| B24 | Cat5 Pin1   | Ethernet                            |
| B25 | Cat5 Pin6   | Ethernet                            |
| B26 | Cat5 Pin3   | Ethernet                            |